

Overview

A properly functioning chemical hood is an important safety device in a laboratory. The chemical hood protects users from inhalation hazards by constantly pulling air into the hood and exhausting it out of the building. Chemical hoods can also provide some protection in the event of an explosion or fire. This Update provides guidance on the usage of chemical hoods at Weill Cornell Medicine (WCM).

Applicability

This procedure applies to:

- All laboratory personnel who use chemical hoods.
- Engineering & Maintenance (E&M) and External Contractors working with or repairing WMC chemical hoods.
- Project Managers installing or renovating chemical hoods.

Responsibilities

Environmental Health and Safety (EHS) advises laboratory personnel of proper hood procedures, ensures that chemical hoods are surveyed annually with a calibrated anemometer, reports hood malfunctions to laboratory personnel and E&M immediately, and performs follow-up airflow surveys promptly after hood repairs are completed.

Principal Investigators and Laboratory Managers establish policies and procedures in their laboratories to ensure compliance with regulatory and institutional requirements and ensure that their personnel are trained and use chemical hoods safely and responsibly.

Laboratory Personnel use hoods according to recommended guidelines for safe use, and coordinate modifications, maintenance, repair, and new equipment needs with EHS and/or Engineering & Maintenance.

Engineering and Maintenance performs preventive maintenance on fans, ductwork, and hoods, makes repairs or maintenance as identified by annual surveys or by users, notifies EHS and coordinates with laboratory personnel when hoods must be turned off for repair, maintenance, or other operations. Engineering and Maintenance will notify EHS to certify a hood that has been repaired.


Project Managers ensure that chemical hoods are commissioned and working properly at the completion of a project.

Procedure

The New York City Fire Department requires all chemical hoods to operate at an average minimum face velocity of 80 to 120 feet per minute (fpm).

A chemical hood should be used when:

- Handling chemicals with significant inhalation hazards such as toxic gases, toxic chemical vapors, volatile radioactive material, and respirable toxic powders
- Carrying out experimental procedures with strong exothermic reactions
- Handling chemicals with significant vapor pressure
- Chemical vapors could cause a fire hazard
- Working with compounds that have an offensive odor (e.g., beta-mercaptoethanol).



RATING CLASSIFICATIONS

All chemical hood surveys are conducted at a sash height of 18”.

- **PASS** - average face velocity between 80 and 150 fpm. The optimum range for face velocity is 80 to 120 fpm.
- **RESTRICTED USE ONLY** - average face velocity between 151 and 180 fpm. Laboratories should not use acutely toxic, highly hazardous, or carcinogenic chemicals.
- **FAIL** - average face velocity less than 80 fpm or greater than 180 fpm.





USER GUIDELINES (STANDARD OPERATING PROCEDURES)

- Position the hood sash to a maximum opening of 18 inches to ensure proper airflow velocities. Adjust the sash lower to shield from splashes, flying objects, and incidents in the hood. Best practice is to work with the sash as low as possible while conducting work.
- Keep hood storage to an absolute minimum. Do not take up hood space and block ventilation by storing unused equipment or chemicals in hoods. If large items must be kept in the hood, contact EHS for evaluation, certification, and a smoke test.
- Keep all work at least six inches inside the hood. The capture ability of a hood may not be 100% at the front of the hood.
- Avoid cross drafts. Someone walking rapidly past the work opening can create a cross draft that may disturb the direction of airflow and cause turbulence.
- Keep the hood clean. Remove old experimental glassware and clutter. Wipe up spilled chemicals or residues. Ensure the glass sash remains clear for good visibility.
- Do not heat **perchloric acid** in standard chemical hoods. Perchloric vapors may create explosive perchlorates in the ductwork. Contact EHS if you are performing perchloric acid digestions.
- Confirm that the chemical hood is operational. Check the air flow gauge or flow monitor if so equipped. Check a telltale (a piece of paper attached to the bottom of the sash). The telltale should be noticeably pulled toward the back of the hood.
- Avoid opening and closing the hood sash rapidly and avoid swift arm movements in front or inside the hood. These actions may cause turbulence and reduce the effectiveness of hood containment.
- Use extreme caution with ignition sources inside a hood. Ignition sources such as electrical connections and equipment, hot plates, controllers, and open flame can ignite flammable vapors or explosive particles from materials being used in the hood.
- Never put your head inside a hood while operations are in progress.
- Report airflow problems and problems with the physical structure of the chemical hood to EHS as soon as possible. If a hood fails while working with highly hazardous materials, immediately close the sash, leave the area and contact EHS for assistance.
- Close or lower the sash to a 2" opening when the hood is not being used.

CHEMICAL HOOD SURVEYS AND MAINTENANCE

EHS surveys all chemical hoods on an annual basis to verify that the air velocity at the opening is within an acceptable range. The Chemical Hood Test Record label is affixed to the external surface of the hood and will indicate the inspection date, the average face velocity measurement at 18" sash height, and the rating classification (e.g., Pass, Restrict, or Fail).

RESTRICTED USE: EHS will conduct a hazard assessment of the operations conducted in the hood, inform laboratory staff and post a sign on the hood indicating which materials and specific uses are acceptable until it is repaired and re-certified.

FAIL TEST: EHS will post a sign on the hood informing laboratory staff not to use the hood until it is repaired and re-certified.

REPAIRS: EHS will automatically submit a **work order** to E&M to repair all non-passing hoods and post a sign on the chemical hood to notify laboratory personnel. E&M conducts repairs to chemical hoods and flow monitors and notifies EHS when repairs are completed. EHS will re-survey the hood to verify the air flow is at passing levels and communicate results to the laboratory.

SHUTDOWN NOTIFICATION

Minor shut downs affecting only a few hoods: notifications will be placed directly on each hood affected.

Large shutdowns affecting large areas (e.g. an entire building): notifications will be posted in elevators and other public areas.

DUCTLESS CHEMICAL HOODS

Laboratories who plan to purchase ductless chemical fume hoods must inform EHS to schedule an evaluation of the authorized uses and materials for each specific hood, as well as filter models, capabilities, and change out schedules. For additional information, consult the [WCM Chemical Hygiene Plan](#).

References

[OSHA Laboratory Standard 29CFR 1910.1450](#)

New York City Fire Code and [FDNY C-14 Study Material](#)

[EHS Chemical Hygiene Plan](#)